

## INSTALLATION MANUAL



### Casa XXS/XS/S/M



















Connect the luminaire to a constant current driver matching specified current and voltage. Direct connection to mains will damage the light source.





### IMPORTANT NOTICE

To ensure safety and correct operation, please follow these guidelines during installation and use. Compliance with these instructions is strongly recommended.

### **SAFETY WARNING**

Before starting installation, or carrying out any maintenance, always disconnect the luminaire from the power supply.

Do not attempt to alter or tamper with the product in any way. Unauthorised modifications may compromise safety and create hazardous situations.

Karizma Luce is not liable for any damages or risks resulting from modified products. This product is intended exclusively for indoor use.

#### **CARE & CLEANING TIPS**

To clean the luminaire, gently wipe it with a soft cloth dampened with water.

For stubborn dirt, use a small amount of mild soap or detergent.

Do not use alcohol, solvents, or harsh chemicals, as these may damage the surface or components.

Dispose of luminaires separately from household waste in accordance with the WEEE Directive.



Warning - Follow safety instructions



Attention - important information, please read carefully



CE marking - complies with EU safety, health, and environmental requirements



Dispose separately from household waste in accordance with WEEE Directive









## INSTALLATION MANUAL




### **INSTALLATION OF LUMINAIRES**

#### PREPARATION:


- Carefully read the manual before installation to guarantee the correct and safe operation of the luminaire.
- Turn off the electricity at the mains before proceeding with the installation of the luminaire.
- Mount the luminaire on a flat, smooth surface.


### PLEASE NOTE: THE LUMINAIRE MUST BE INSTALLED BY QUALIFIED PERSONNEL!


The following instructions are valid for all versions of the Casa luminaire.



	luminaire ø	Н	cut out ø	Α	В	С	max tilt
Casa XXS	038mm	43mm	ø30mm	70mm	73mm	8 - 20mm	-
Casa XS	045mm	66mm	040mm	70mm	93mm	8 - 20mm	-
Casa XS Swing	045mm	64mm	040mm	70mm	94mm	8 - 20mm	30°
Casa S	ø57mm	81mm	ø50mm	70mm	Illmm	8 - 20mm	-
Casa S Swing	057mm	92mm	ø50mm	70mm	122mm	8 - 20mm	30°
Casa M	068mm	93mm	060mm	70mm	123mm	8 - 20mm	-
Casa M Alto	068mm	106mm	060mm	70mm	136mm	8 - 20mm	-
Casa M Swing	068mm	106mm	Ø60mm	70mm	136mm	8 - 20mm	30°








# INSTALLATION MANUAL





TO UNINSTALL THE LUMINAIRE, FOLLOW ABOVE STEPS IN REVERSE.